

NOTE DI ASSEMBLAGGIO / ASSEMBLY NOTE page 1/4

H128COLLBI
Honda CRF 450R '15
KIT

01



02



SMONTAGGIO SILENZIATORE ORIGINALE

- Svitare le viti di fissaggio della fiancatina (Fig. 01,02);
- Svitare la fascetta di innesto del silenziatore (Fig. 03);
- Rimuovere i silenziatori svitando le viti di fissaggio al telaio (Fig. 04,05,06);
- Svitare i dadi della ghiera sul collettore (Fig. 07,08), conservare i dadi originali poiché torneranno utili per il montaggio del Kit Termignoni;
- In fine rimuovere il collettore;

03



04



DISMOUNTING THE ORIGINAL SILENCER

- Unscrew the fixing screws of the side panels (Pic. 01,02);
- Loosen the clamp to the silencer (Pic. 03);
- Remove silencers unscrewing the mounting screws from the frame (Pic. 04,05,06);
- Unscrew the nuts on the collector ring (Pic. 07,08), preserve the original nuts to put on the Kit Termignoni;
- Remove the collector;

05



06



07



08



NOTE DI ASSEMBLAGGIO / ASSEMBLY NOTE page 2/4

H128COLLBI
Honda CRF 450R '15
KIT

09



10



MONTAGGIO DEL KIT TERMIGNONI

- Montare la ghiera sulla boccola e alloggiarle nell'attacco testa, fissandole con i dadi originali senza serrare (Fig. 09);
- Inserire il collettore nella boccola e fissarlo con la molla corta con gommino, utilizzando il tira-molla in dotazione (Fig. 10, 11);
- A seguire, il montaggio del silenziatore Termignoni;
- Posizionare la molletta filettata M8 sulla staffa supporto corpo centrale (Fig. 12);
- Innestare il corpo centrale sul collettore e fissarlo al telaio con la vite M8x25 e la rondella 8x16, in dotazione, senza serrare (Fig. 13, 14);
- Agganciare la molla tra corpo centrale e collettore (Fig. 15);

11



12



13



14



15



MOUNTING THE TERMIGNONI KIT

- Mount the flange on the bushing and place them into the cylinder head, fixing all with the original nuts without tightening (Pic. 09);
- Insert the collector into the bushing and fix it with short spring with rubber, using the pull springs, in the pack (Pic. 10, 11);
- Below, the mounting of the Termignoni silencer
- Position the clip M8 on the central body support bracket (Pic. 12);
- Insert the central body into the collector and fix it at the frame with the screw M8x25 and the washer 8x16, in the pack, without tightening (Pic. 13, 14);
- Hook the spring between the central body and the collector (Pic. 15);



TERMIGNONI S.p.A.

Via della Rampina n°1
15077 Predosa – Italy
www.termignoni.it

Tel. 0039.0131.71666
Fax 0039.0131.71696
info@termignoni.it

NOTE DI ASSEMBLAGGIO / ASSEMBLY NOTE page 3/4

H128COLLBI

Honda CRF 450R '15

KIT

18



19



MONTAGGIO DEL KIT TERMIGNONI

•Posizionare i distanziali in alluminio sulla staffa supporto silenziatore, tenendo il distanziale più spesso e il distanziale in teflon sul lato interno (Fig. 18,19);

•Innestare i silenziatori al corpo centrale (Fig. 20);
•Fissare i silenziatori al telaio con le viti M8x35 e le rondelle 8x24, in dotazione, partendo dal silenziatore sinistro (Fig. 21,22);

•Agganciare le molle corte con gommino (Fig. 23,24);

•Ora serrare tutte le viti iniziando dalla staffa supporto silenziatore (Fig. 25,26);

•In fine rimontare le fiancatine e la sella.

20



21



22



23



MOUNTING THE TERMIGNONI KIT

•Position the aluminum spacer on the silencer support brackets, taking the thicker spacer and the spacer teflon on the inner side (Pic. 18,19);

•Insert the silencers to the central body (Pic. 20);
•Fix the silencers to the frame with the screws M8x35 and the washers 8x24, in the pack, starting from the left silencer (Pic. 21,22);

•Hook the short springs with rubber (Pic. 23,24);

•Now tighten all the screws starting from the one of the silencer support bracket (Pic. 25,26);

•In order remount the side panels and the seat.

24



25



26





TERMIGNONI S.p.A.

Via della Rampina n°1
15077 Predosa – Italy
www.termignoni.it

Tel. 0039.0131.71666
Fax 0039.0131.71696
info@termignoni.it

DOTAZIONE / PACKING LIST page 4/4

H128COLLBI

Honda CRF 450R '15

KIT

N°1 COLLETTORE - COLLECTOR H128COLLBI

N°1 BOCCOLA - BUSHING cod. TH055

N°1 GHIERA - FLANGE cod. TH054

N°2 MOLLE CORTE CON GOMMINO - SHORT SPRINGS WITH RUBBER cod. TER009

N°1 TIRA-MOLLA - PULLS SPRING cod. TER343

